

No.	File Name	Description
1	MROI-001	Mirror cell 01
2	MROI-002	Mirror cell 02
3	MROI-003	Mirror cell screw
4	MROI-004	Pressure cup
5	MROI-005	Mirror cell screw
6	MROI-006	Back Plate
7	MROI-007	Back plate screw bush
8	MROI-008	Back plate pressure tip
9	MROI-009	C-Flex bearing base 01
10	MROI-010	C-Flex bearing base 02
11	MROI-011	Back wishbone leg
12	MROI-012	Back wishbone leg base
13	MROI-014	Bulkhead
14	MROI-020	Front wishbone leg
15	MROI-021	Front wishbone leg base 01
16	MROI-022	Front wishbone leg base 02
17	MROI-024	Voice coil holder
18	MROI-025	Bulkhead support
19	MROI-029	Crank (steering)
20	MROI-030	Link (steering)
21	MROI-031	Steering arm
22	MROI-032	Cap (steering)
23	MROI-033	Bracket support (steering)
24	MROI-034	Rear wheel bracket
25	MROI-035	Steering plate
26	MROI-036	Motor base
27	MROI-037	Bar (rear base)
28	MROI-038	Rear base
29	MROI-040	Bracket of A.S.
30	MROI-041	Bracket of front wheels
31	MROI-042	Bracket of position sensor
32	MROI-043	Precision washer 01
33	MROI-044	Precision washer 02
34	MROI-049	Front segment (bottom shell)
35	MROI-050	Rear segment (bottom shell)
36	MROI-051	Middle segment (bottom shell)
37	MROI-052	Plate support
38	MROI-054	Bottom shell (for further machining)
39	MROI-055	Magnet holder
40	MROI-056	Cats eye stop
41	MROI-057	Top shell (for further machining)
42	MROI-059	Side plate 1 & 2 (for further machining)
43	MROI-060	Angle support
44	MROI-061	Frame support
45	MROI-062	Frame support
46	MROI-063	Frame support
47	MROI-064	Transformer bracket 01

48	MROI-065	Back plate (trolley)
49	MROI-066	Transformer bracket 02
50	MROI-067	Insulating pad (transformer)
51	MROI-068	Insulating bush (transformer)
52	MROI-069	Front plate (trolley)
53	MROI-070	Wedge
54	MROI-071	Wedge frame
55	MROI-072	Assembly – Pipe support
56	MROI-073	Pipe cradle
57	MROI-074	Pipe support leg
58	MROI-075	Pipe support base
59	MROI-076	Flexure pad
60	MROI-077	Flexure clamp
61	MROI-078	Anchor support
62	MROI-079	Pipe support angle
63	MROI-080A	Pipe support plate 01
64	MROI-080B	Pipe support plate 02
65	MROI-081	Top insert
66	MROI-082	Pipe support plate
67	MROI-083	Assembly – Pipe anchor
68	MROI-084	Pipe section 2
69	MROI-085	Pipe lug -1
70	MROI-086	Pipe lug -2
71	MROI-087	Assembly – NMT test rig
72	MROI-088	Pipe section 3
73	MROI-089	Clamping strip
74	MROI-090	Pillar pad
75	MROI-1050	Assembly flexure CFRP tube
76	MROI-1100	Interface ring (CFRP tube)
77	MROI-1105	Sub assy – cats eye
78	MROI-1150	CFRP tube bonded assy
79	MROI-1500	Secondary slide outer
80	MROI-1505	Secondary slide inner
81	MROI-1510	Secondary slide parts
82	MROI-1600	Support frame secondary
83	MROI-1650	Pivot block
84	MROI-2000	Carriage tube assembly
85	MROI-2005	Frame secondary assembly